

Control Air Instrument Plate

Installation & Maintenance Instructions

INSTALLATION

Installation of Airtech Products Control Air transducer and filter regulator instrument plate is a simple four-step process:

1. Attaching the actuator and instrument plate to louver frame
2. Connection of air lines and control signal
3. Connection of linkage
4. Recalibration of I/P (transducer)

Before starting installation, inspect the actuator and instrument plate to ensure all required parts are present. Check the following:

- Confirm all parts are firmly secured to the mounting plate
- Confirm a .25" fitting has been installed (use standard Teflon tape) at actuator housing inlet port
- Confirm the clevis is present at the threaded end of the actuator stem
- Confirm the following are present to complete the installation:
 1. Three (3) .25"-.625" long bolts w/Keps nuts (shipped installed on plate attachment angle)
 2. Pivot mount for attachment of actuator to mounting bracket
 3. Bolts to attach actuator to pivot mount




1) Attach the actuator and instrument plate:

1. The instrument plate can be mounted on either horizontal or vertical louvers using the attachment angle factory mounted to the appropriate side of the plate.
2. Note the instructional sticker advising the "UP" direction for installation.
3. The mounting plate is supplied with three (3) .25" bolts to fasten the attachment angle to the louver at pre-drilled and tagged location on the louver frame.



4. Set the instrument plate in place and align holes in frame w/holes in attachment angle
5. Attach plate to frame using the supplied .25" diameter bolts/nuts.
6. Tighten securely



7. Attach the pivot mount to the actuator body using four (4) supplied .375 x .75" diameter bolts.
8. Attach the pivot mount to the actuator support bracket
9. **DO NOT ATTACH THE ACTUATOR CLEVIS TO THE TORQUE TUBE LEVER ARM YET.**

2) Air Line Connections:

1. Blow out all piping before connections are made to prevent dirt, chips, etc from entering the actuator body or filter regulator.
2. Attach SS braided air-line from filter reg set to supplied 1/4" threaded adapter in the air inlet port on top cap of actuator. Use Teflon tape or non-hardening sealant when installing connector in actuator.
3. Connect plant air (150 psig suggested maximum) to filter regulator.

2a) Control Signal Connection:

1. Locate the electrical lines and conduit connection port on the transducer and install male adapter.
2. Connect conduit and thread wiring into transducer connection terminals
3. Connect leads for control signal to corresponding terminals in transducer.

3) Connecting The Linkage:

1. In most cases, the torque tube lever arm will be set to "Fail Open" upon loss of air and / or actuator retraction. As a result, connection of the linkage will be a simple matter of manually situating the louver blades and actuator stem to the correct position and then attaching the control link to the clevis (at the base of the actuator stem) and finally to the torque tube lever arm. To determine how the actuator and louver blades should be positioned, please note the following instructions:
 - a. **"Fail Open" Louvers**
 - Stroke actuator to fully extended and manually set louver to fully closed position before connecting louver lever arm & link to actuator clevis.
 - b. **"Fail Closed" Louvers**
 - Ensure actuator is completely retracted and manually set louvers to fully closed position before connecting louver lever arm & link to actuator clevis.
2. When assembly and installation work is complete, stroke the actuator several times to ensure it moves the entire louver freely without binding or interference. Some adjustment of end links or torque tube clamps may be required to ensure all louver blades open and shut consistently down the entire length or across the entire width of the louver.
3. Check all attachment fasteners to ensure all are properly tightened and completely engaged to the louver flange.
4. If applicable, check all end link connections and torque tube couplers to ensure they are properly tightened and fasteners are completely engaged.

4) Check I/P calibration and reset if needed:

1. The I/P (transducer) has been factory calibrated to output a 6 psi – 45 psi pressure in proportional response to receipt of 4-20 mA control signal however normal handling and shipping may require recalibration of transducer input vs output.
2. Specific instructions for that recalibration are included in an envelope attached directly to the I/P. Please refer to that document for instructions on how to recalibrate.
3. The tech data cut sheet and recalibration instructions are included as pages 4-8 of this document.

Type 500X

Electropneumatic Transducer (I/P, E/P) Installation, Operation and Maintenance Instructions



Ordering Information


Type 500X I/P Transducers

Part Number	Input	Output Range		Impedance
		psi	kPa	
500-AA	4-20 mA	3-9	20-60	90 Ohms
500-AB	4-20 mA	9-15	60-100	90 Ohms
500-AC	4-20 mA	3-15	20-100	180 Ohms
500-AD	4-20 mA	3-27	20-185	220 Ohms
500-AE	4-20 mA	6-30	40-200	220 Ohms
500-AF	4-20 mA	1-17	7-117	250 Ohms
500-BC	10-50 mA	3-15	20-100	70 Ohms
500-BD	10-50 mA	3-27	20-185	85 Ohms
500-BE	10-50 mA	6-30	40-200	85 Ohms
500-AG	4-20 mA	2-60*	14-420	225 Ohms
500-AH	4-20 mA	3-120*	20-830	260 Ohms
500-BF	0-60 mA	2-120*	15-830	220 Ohms

Type 500X E/P Transducers

Part Number	Input	Output Range		Impedance
		psi	kPa	
500-CC	0-5 VDC	3-15	20-100	615 Ohms
500-CD	0-5 VDC	3-27	20-185	530 Ohms
500-CE	0-5 VDC	6-30	40-200	530 Ohms
500-DC	1-9 VDC	3-15	20-100	985 Ohms
500-DD	1-9 VDC	3-27	20-185	840 Ohms
500-DE	1-9 VDC	6-30	40-200	840 Ohms
500-CF	0-5 VDC	2-60*	14-420	500 Ohms
500-EH	0-10 VDC	3-120*	20-830	805 Ohms

*Output shown is as calibrated at the factory. Large span adjustment capability allows recalibration to achieve output ranges from 3-35 psig (20-240 kPa) with 2-60 psig unit to 3-145 psig (20-1000 kPa) with 2-120 psig unit.



Contents

Section	Description	Page
1.0	Description & Installation	2
2.0	Operation	3
3.0	Maintenance	5
4.0	Troubleshooting	5
5.0	Warranty	5



8 Columbia Drive
Amherst, NH 03031 USA
603-886-9400
Fax: 603-889-1844
www.controlair.com
sales@controlair.com



DANGER, WARNING, CAUTION and NOTE statements

DANGER Refers to conditions or hazards which could result in serious personal injury or death.

WARNING Refers to conditions or hazards which could result in personal injury.

CAUTION Refers to conditions or hazards which could result in equipment or property damage.

NOTE Alerts you to facts or special instructions.

ALL DANGER, WARNING, AND CAUTION NOTICES MUST BE COMPLIED WITH IN FULL

SPECIFICATIONS

Min./Max. Supply Pressure	Minimum - 3 psig (21 kPa) Above maximum output Maximum - 100 psig (700 kPa)
Supply Pressure Sensitivity	$<\pm 0.1\%$ of span per psig ($<\pm 0.15\%$ of span per 10 kPa)
Linearity	$<\pm 0.75\%$ of span
Repeatability	$< 0.5\%$ of span
Hysteresis	$< 1.0\%$ of span
Flow Rate	4.5 scfm (7.6 m ³ /hr ANR) at 25 psig (175 kPa) supply 12.0 scfm (20.0 m ³ /hr ANR) at 100 psig (700 kPa) supply
Maximum Air Consumption	.05 scfm (.07 m ³ /hr) midrange typical
Port Sizes	1/4 NPT (Pneumatic) 1/2 NPT (Electric)

1. DESCRIPTION and INSTALLATION

1.1 Description

- 1.1.1 The ControlAir Type 500X converts a current or voltage input signal to a linearly proportional pneumatic output pressure. This versatile instrument is designed for control applications that require a high degree of reliability and repeatability at an economical cost.

1.2 Principle of Operation

- 1.2.1 The Type 500X is a force balance device in which a coil is suspended in the field of a magnet by a flexure. Current flowing through the coil generates axial movement of the coil and flexure. The flexure moves towards the nozzle and creates back pressure which acts as a pilot pressure to an integral booster relay. Input signal increases (or decreases for reverse acting) cause proportional output pressure increases.

Zero and Span are calibrated by turning adjust screws on the front face of the unit. Adjustment of the zero screw repositions the nozzle relative to the flexure. The span adjustment is a potentiometer that controls the amount of current through the coil.

1.3 Mounting

- 1.3.1 Unit may be pipe, panel, or bracket mounted. Mounting may be at any angle, though may require field adjustment. High external vibration may cause output fluctuations. Mounting in a vibration-free area is recommended.

1.4 Pneumatic Connections

- 1.4.1 The 1/4 NPT supply and output ports are marked "IN" and "OUT" respectively on the base of the unit. Clean all pipe lines to remove contamination before installation. Apply pipe compound to male threads of the air line only. Avoid getting compound in the air lines.


Clean dry instrument quality air must be used. To insure optimum performance supply pressure should be regulated. To provide stable inlet pressure and prevent contamination of the internal section of the transducer the use of an Instrument Air Filter Regulator is recommended.

The two unmarked ports on the base of the unit are gage ports but may be used as alternative output ports. Any unused ports must be plugged.

1.5 Electrical Connections

- 1.5.1 Electrical connections are made to the black and white leads extending out from the 1/2 NPT conduit fitting. When the positive side of the input signal is connected to the black lead, the output pressure will increase as the input signal increases. For reverse acting mode (increasing input signal decreases output pressure), connect positive side of the input signal to the white lead.

Figure 1 DIN 43650 Connector



2. OPERATION

2.1 Calibration

- 2.1.1 Zero and Span should always be checked after mounting. If unit is calibrated in a vertical position and then mounted at an angle, readjustment of the zero is necessary. To calibrate use the following procedure:
1. Open protective covers to expose zero and span adjustment screws.
 2. Connect the recommended air supply to the inlet of the transducer and an accurate pressure gage to the outlet.
 3. Connect the electrical input and set the input signal to the minimum value of the range being used (e.g. 4 mA for a 4-20 mA unit).
 4. Observe the output pressure. If necessary adjust zero screw until reaching minimum output pressure setting. Turn zero screw counter clockwise to increase pressure, clockwise to decrease pressure.


NOTE *If unable to achieve output during calibration process, turn zero adjustment screw counter clockwise for up to 30 revolutions, until output pressure rises.*

5. Increase electrical input signal to its maximum value (e.g. 20 mA for a 4-20 mA unit).
6. Observe the output pressure. If necessary adjust the span screw until reaching maximum output pressure setting.

NOTE *For I/P (current) input models turn span screw counter clockwise to increase pressure, clockwise to decrease pressure. For E/P (voltage) input models turn span screw clockwise to increase pressure, counter clockwise to decrease pressure.*

7. The Zero and Span adjustments are interactive. After adjusting the span it will be necessary to recheck the zero. Repeat steps 3-6 until both end points are at the required values.
8. For reverse acting performance interchange the black and white electrical signal leads and carry out the same procedure as described above. Adjust the zero screw with minimum input (4mA) to get maximum output then adjust span screw with maximum input (20mA) to get minimum output. Repeat as necessary.


Figure 2 Electrical Schematic



Notes:


1. For 4-20 mA and 10- mA use J1 as positive input.
2. For 10-50 mA change R4 to 100 Ohms.
3. For 1-9 VDC and 0-10 VDC remove R2, use J5 as positive input.

2.2 Dimensional Drawings (Dimensions are $\frac{\text{in.}}{\text{mm}}$)



2.3 Intrinsically Safe Operation

2.3.1 ControlAir, Inc. offers Factory Mutual Intrinsically Safe approval as a standard feature on all units with a 4-20 mA input signal.



- NOTES:
1. INSTALLATION TO BE IN ACCORDANCE WITH THE NATIONAL ELECTRIC CODE, NFPA 70, ARTICLE 504, AND ANSI/ISA 81.16.1.
 2. APPARATUS CONNECTED TO THE SYSTEM SHALL NOT USE OR GENERATE VOLTAGE GREATER THAN 250 V.
 3. INSTALL INTRINSICALLY SAFE BARRIERS IN ACCORDANCE WITH BARRIER INSTRUCTIONS.
 4. FACTORY MUTUAL APPROVED AS INTRINSICALLY SAFE FOR CLASS I, X, AND II, DIVISION 1, GROUPS C, D, E, F, AND G, WHEN INSTALLED AS SHOWN ON SHEET 1 AND 2. UNITS WITH 'D' OPTION ARE FACTORY MUTUAL APPROVED AS INTRINSICALLY SAFE FOR CLASS I, DIVISION 1, GROUPS C, D WHEN INSTALLED AS SHOWN ON SHEET 1 AND 2.
 5. FACTORY MUTUAL APPROVED AS NONINDUCIVE FOR CLASS I, DIVISION 2, GROUPS A, B, C, AND D, AND SUITABLE FOR CLASS I, DIVISION 1, GROUP F, G AND CLASS II, DIVISION 1 AND 2. UNITS WITH 'D' OPTION ARE FACTORY MUTUAL APPROVED AS NONINDUCIVE FOR CLASS I, DIVISION 2, GROUPS A,B,C,D WHEN INSTALLED AS SHOWN ON SHEET 1 AND 2. BARRIERS ARE NOT REQUIRED FOR NONINDUCIVE RATING MAX V=250 VDC.
 6. CAUTION! SUBSTITUTION OF COMPONENTS MAY VOID FACTORY MUTUAL APPROVAL.
 7. AMBIENT TEMPERATURE RANGE: -30° C TO 60° C.
 8. FACTORY MUTUAL APPROVED AS INTRINSICALLY SAFE FOR CLASS I, X, AND II, DIVISION 1, GROUPS C, D, E, F, AND G, WHEN USED WITH AN APPARATUS MEETING THE FOLLOWING ENTITY REQUIREMENTS:
 $V_{max} = 25.9V$ C_{M0}
 $I_{max} = 65mA$ $L \leq 35mH$
 9. FOR DIN CONNECTOR OPTION, ADD 'D' TO THE MODEL NUMBER.
 10. FOR NEMA 4X OPTION, ADD 'X' TO THE MODEL NUMBER. ONLY THE STANDARD 1/2" NPT CONDUIT IS SUITABLE FOR NEMA 4X INSTALLATIONS. UNITS WITH 'D' CONNECTION MUST BE MOUNTED IN A SUITABLE ENCLOSURE.
 11. MODELS WITH NEMA 4X OPTION ARE FACTORY MUTUAL APPROVED FOR INDOOR/OUTDOOR USE PER THE REQUIREMENTS OF NEMA 4X AS DESCRIBED IN THE NATIONAL ELECTRICAL MANUFACTURERS ASSOCIATION STANDARD NO. 250 'ENCLOSURES FOR ELECTRICAL EQUIPMENT, 1000 VOLTS MAX'.

Drawing No. 431-990-013


Models 728+, 787S+ and 4045, +24 to +26 VDC, Model 728-, -24 to -26 VDC, available from MTL Inc. 7541 Gary Road, Manassas, VA 22110, USA.

3. MAINTENANCE

Under normal circumstances, no maintenance should be required. If clean dry air is not used the orifice can become blocked. To clean, first turn off supply air, unscrew and remove orifice assembly (large silver screw head located above the out port). Then unplug orifice by using a wire that has a smaller diameter than 0.015 in. (0.38 mm). Use compressed air to blow out any loose particles inside the orifice assembly. Screw orifice assembly back into unit.

4. TROUBLESHOOTING

PROBLEM	CHECK
No output or low output	Zero adjustment Supply pressure too low Clogged orifice
Leakage	Connections
Low or improper span	Zero and Span adjustments Supply pressure too low Output leakage
Erratic operation	Electrical input signal Loose wires or connections Liquid in air supply



5. WARRANTY & DISCLAIMER

ControlAir, Inc. products are warranted to be free from defects in materials and workmanship for a period of eighteen months from the date of sale, provided said products are used according to ControlAir, Inc. recommended usages. ControlAir, Inc.'s liability is limited to the repair, purchase price refund, or replacement in kind, at ControlAir, Inc.'s sole option, of any products proved defective. ControlAir, Inc. reserves the right to discontinue manufacture of any products or change products materials, designs or specifications without notice.

WARNING *These products are intended for use in industrial compressed-air systems only. Do not use these products where pressures and temperatures can exceed those listed under Specifications.*

Before using these products with fluids other than air, for non-industrial application, life-support systems, or other applications not within published specifications, consult ControlAir, Inc.